

## Application Example: Quality control at automotive supplier GEDIA

Measurement system: ATOS, ATOS ScanBox

Keywords: Automotive, sheet metal, automatic shape and dimension control, production-related quality control, press shop, tactile metrology, optical 3D metrology

The automotive supplier GEDIA is taking a new approach to quality control: The company is replacing measuring technology based on tactile systems and gauges with full-surface optical 3D coordinate measurement. The implementation of optical metrology systems is making GEDIA more flexible. It is cutting costs and reducing measurement times.



**GOM mbH**  
Mittelweg 7-8  
38106 Braunschweig  
Germany  
Tel +49 531 390 29 0  
Fax +49 531 390 29 15  
info@gom.com

**GOM International AG**  
Bremgartnerstrasse 89B  
8967 Widen  
Switzerland  
Tel +41 5 66 31 04 04  
Fax +41 5 66 31 04 07  
international@gom.com

**GOM UK Ltd**  
Unit 14 The Cobalt Centre  
Coventry, CV3 4PE  
United Kingdom  
Tel +44 2476 639920  
Fax +44 2476 516990  
info-uk@gom.com

**GOM France SAS**  
10 Quai de la Borde  
91130 Ris Orangis  
France  
Tel +33 1 60 47 90 50  
Fax +33 1 69 06 63 60  
info-france@gom.com

**GOM Branch Benelux**  
Interleuvenlaan 15 F  
3001 Leuven  
Belgium  
Tel +32 16 408 034  
Fax +32 16 408 734  
info-benelux@gom.com

**GOM Italia Srl**  
Via della Resistenza 121/A  
20090 Buccinasco (MI)  
Italy  
Tel +39 02 457 01 564  
Fax +39 02 457 12 801  
info-italia@gom.com

## Application Example: Quality control at automotive supplier GEDIA

Measurement system: ATOS, ATOS ScanBox

Keywords: Automotive, sheet metal, automatic shape and dimension control, production-related quality control, press shop, tactile metrology, optical 3D metrology

Founded in 1910, GEDIA Gebrüder Dingerkus GmbH develops and produces structural parts and assemblies for automotive car body manufacturing. The company is based in Attendorn, Germany, and operates additional production sites in Poland, Spain, China and Mexico. All plants manufacture pressed, stamped and drawn parts for the automotive industry. The company also runs engineering centers in France, the U.S.A. and Sweden.

### Technological leadership as corporate goal

Until today, GEDIA has focused on tactile measurement, using coordinate measuring devices and gauges for quality control of assemblies and in toolmaking. However, this approach to measurement reached its limits as the company grew and expanded its sites, e.g. at Attendorn. Particularly the inspection of sheet metal parts became time-consuming and labor-intensive, as all parts had to be transported several hundred meters from the press or joining plants to the central measuring room. In order to streamline the process, the decision was made to have the measuring system come to the component, instead of transporting the component to the measuring system. However, this would require mobile measuring equipment designed for use in production.

The new quality control approach is an important step in realizing GEDIA's goal of leading the industry in production technology. As a consequence, the changeover from traditional tactile systems to full-surface optical 3D coordinate measurement is being implemented worldwide at all production sites and at all relevant facilities, such as press shops, joining plants and assembly. (Fig. 1)



Fig. 1: GEDIA will implement the full-surface optical 3D coordinate measurement worldwide at all production sites and at all relevant facilities, such as press shops, welding shops and assembly.

### **Larger scale production requires shorter measurement times**

Like many companies that have to adjust their processes to accommodate increased production levels, GEDIA was challenged to find a way to cut measurement times. At the same time, quality had to be maintained, although cycle times grew shorter and production output increased. However, the relatively slow tactile measurement of parts, which often have complex shapes, results in long occupation times and complex logistics, and even then, only a few points on the part are checked.

In order to manage rising output quantities and a constant increase in measuring requirements, GEDIA had to outsource a growing number of measurement tasks to external service providers. This situation had two main drawbacks: Not only did it result in high costs, but it also meant that in-house knowledge had to be shared with parties outside the company. Thus, the aim of the new approach to quality control was to relocate the entire measurement and digitizing expertise back to the company's own workforce.

With this in mind, the quality control and measuring technology experts at GEDIA had four main criteria to consider: The systems needed to deliver full-surface measurements while also being mobile and fast. The company also wanted to regain the complete measuring competence in-house.

### **The approach to optical measurement technology**

After various unsatisfactory trial runs with mobile, tactile devices mounted on articulated arms, it became clear that tactile metrology was not going to meet the company's needs. It was time to completely rethink the measuring technology used. GEDIA launched the transition from tactile to optical metrology by investing in a mobile ATOS 3D scanner for full-surface optical 3D coordinate measurement. This was an important first step toward the company's main goal of keeping its technological leadership. (Fig. 2)

With its fast supply of precise measurement data, the high-resolution optical ATOS 3D digitizer fulfilled the company's criteria. For various sizes and surface characteristics of GEDIA's components and even complex measuring tasks, the optical system offers:

- precise 3D coordinates with high data quality
- parametric inspection and traceable evaluation
- full-surface deviation to CAD, or from part to part
- evaluation according to 2D drawings
- inspection sections, geometric dimensioning and tolerancing (GD&T) as well as trend analysis
- complete, clearly presented measurement reports




Fig. 2: GEDIA launched the transition from tactile to optical metrology by investing in a mobile ATOS 3D scanner for full-surface optical 3D coordinate measurement. The measurement data can be analyzed immediately and compared directly with the CAD data. Deviations to CAD are highlighted in color and problematic areas are easy to recognize, enabling specific improvements to be made to the manufacturing process.

Used for measuring tools and forming dies, but also for the measurement of sheet metal parts, the manual ATOS system quickly demonstrated that GEDIA could significantly benefit from optical measurement technologies. From prototype development to serial production measurement, part analysis, digitizing up to virtual joining of assemblies – all of these tasks can be performed by a single technology, as opposed to the much less versatile tactile measuring method.

An additional benefit with full-surface measurement is that it makes efficient tool corrections easier, and, as a result, fewer iterations are required before a tool is approved. By measuring the final tool contours with the ATOS scanner, it is also possible to keep CAD data for the tool up to date. This enables copy milling of tools based on ATOS data. (Fig. 3)



Fig. 3: The optical measuring systems make efficient tool corrections easier, and, as a result, fewer iterations are required before a tool is approved.

The clear, easy-to-read measurement reports generated from full-surface data provide an additional benefit: In contrast to pages of tables from test reports with individual measuring points, they provide significantly better readability and clarity. This reduces the time required for discussing the results, and any necessary correction steps can be implemented quickly and efficiently.

**Next step: automated optical metrology**

The experiences at GEDIA soon led to an additional requirement: In order to make the process more flexible, and more efficient in terms of time and costs, GEDIA wanted to have the optical measurement automated and still mobile.

When a GEDIA-designed customized measuring cell with integrated GOM equipment proved to be a step in the right direction (Fig. 4), the company decided to acquire a standardized, automated measuring cell: the ATOS ScanBox (Fig. 5). As opposed to a customized solution, the ATOS ScanBox comes with all elements required for fully automated 3D digitizing and inspection. The complete system includes hardware, software, worldwide customer service, safety equipment and documentation. As a result, the automotive supplier does not have to worry about any additional planning or investments – all that is needed for operating the turnkey measurement cell on site is the floor space and a power supply.



Fig. 4: The first automated solution at GEDIA: a customized measuring cell with integrated GOM equipment.

One point especially important to GEDIA is that with GOM, the company is cooperating with a single partner for planning, setup, training and support. Even the normally required safety approval can be eliminated: Industrial housing of the measurement cell ensures that there is no safety risk for personnel. Damage to assemblies and components is prevented by means of collision protection.

### Standardized measurement cells at multiple sites

GEDIA's first ATOS ScanBox is in use for production-related quality control at the press shop in Attendorn. The core of the measurement cell, developed with precisely such production applications in mind, is the robot-guided ATOS Triple Scan 3D sensor. Another advantage for the automotive supplier is that the ATOS ScanBox can be directly operated by production staff, as all measurement and inspection processes up to the measurement report can be conducted quickly and easily. This is made possible by the standard software solution VMR (Virtual Measuring Room), which reproduces the actual environment of the ATOS ScanBox down to the smallest detail. As a result, the robot can be operated with simple drag-and-drop commands and without the robot operating panel. In the VMR, even offline programming without any actual parts is possible using CAD data.



Fig. 5: The standardized ATOS ScanBox comes with all elements required for fully automated 3D digitizing and inspection. In GEDIA's Attendorn press plant, it has helped cut measuring times by more than half in comparison with previous tactile solutions.

At the Attendorn press plant, the ATOS ScanBox has helped cut measuring times by more than half in comparison with previous tactile solutions. This has exceeded GEDIA's expectations. In addition, customers are able to work without expensive measuring gauges when using optical measuring technology.

A second ATOS ScanBox is already in use to check the quality of one of GEDIA's most important products, the completely assembled rear end of a German premium car. Even large components can fit into the measurement cell. With regard to different sizes of parts, the ATOS ScanBox series consists of different models.

GEDIA has already entered the planning stage for a third ATOS ScanBox for its press plant in Poland, and additional ScanBoxes will soon follow for the sites in Spain and Hungary. Even though the measurement cells are in use at different locations, GEDIA is still able to centralize its quality management: The measurement and inspection processes with the ATOS ScanBox are standardized and can therefore be applied uniformly at various locations. As a result, the entire quality control process is becoming traceable and transparent.

In the future, GEDIA is going to complete the reorganization of its quality control and it is going to equip all sites with optical measuring systems exclusively – the final step for GEDIA to realize its corporate goal of leading the industry in production technology.